Manual Switches


Buttons/Lens for Switches and Indicators

AML51 PUSHBUTTON ORDER GUIDE (All possible color combinations may not be available.)


For Incandescent or non-lighted display switches and pushbutton style indicators.

AML51-C | **10** | **R** | —


For AML11, 21, 31 switches and AML41 indicators: Pushbutton Style




AML51-C




AML51-F




AML51-G




AML51-A




AML51-H




AML51-N★




AML51-B*



AML51-E*




AML51-M*



AML51-R*

For AML41D indicators only:



AML51-D

* Available with transmitted color (10 or 20) only.
**** Insert is clear for projected color when ''W'' is used.

Display Legend/Type

Transmitted Color
10 No legend
20 With legend on cap.

Transmitted Color (Clear cap and color insert)
11 No legend
21 With legend on insert

Dead Front (Smoky gray cap and color insert)
30 No legend
40 With legend on insert

******Projected Color** (White cap and color insert)
50 No legend
60 With legend on cap

Full Color or 1st Color Split

R Red
Y Yellow
G Green
B Blue
W**** White
K*** Black
L*** Gray
A** Amber

2nd Color Split

R Red
Y Yellow
G Green
B Blue
W**** White
K*** Black
L*** Gray
A** Amber

Example: **AML51-C10R**
Square full color button; with transmitted color, no legend; red.


** Available with transmitted color and dead front only.
*** Black and gray not recommended for lighted display.
† AML51-N buttons not available with Display/Legend Types 10 and 20.
Note: Dimensions include the .060 in bezel.

AML51 LENS ORDER GUIDE (All possible color combinations may not be available.)


For incandescent display AML41J, K, and L lens style indicators only.

AML51-J | **10** | **R**


Lens style



AML51-J



AML51-K



AML51-L

Display/Legend Type

Transmitted Color
10 No legend
20 With legend

Transmitted Color (Clear cap and color insert)
11 No legend
21 With legend

Dead Front (Smoky gray cap and color insert)
30 No legend
40 With legend

******Projected Color** (White cap and color insert)
50 No legend
60 With legend

Full Color or 1st Color Split	2nd Color Split	3rd Color Split
R Red	**R** Red	**R** Red
Y Yellow	**Y** Yellow	**Y** Yellow
G Green	**G** Green	**G** Green
B Blue	**B** Blue	**B** Blue
W**** White	**W****** White	**W****** White
A** Amber	**A**** Amber	**A**** Amber

** Not available with projected color.
**** Insert is clear for projected color when ''W'' is used.

AML51 lens buttons provide added display area by snapping onto and covering the bezel of AML41J, K, and L indicators. They do not fit other indicators or switches.

Example: **AML51-J10R**
Rectangular lens type button; full color; transmitted color, no legend; red.

HOW TO ORDER BUTTON LEGENDS

When specifying legended buttons, submit a legend order sheet to cover each listing. To insure proper legend orientation, AML housings (when viewed from the panel front) should have the ''MICRO SWITCH'' identification facing UP on square devices and UP or to the LEFT on rectangular.

Button legend order sheets are shown on the following pages. Reproduce them on your office copier.

Legend Sheet	Form No.
AML51 Pushbuttons	FO-63394
AML51 Lens buttons	FO-63395
AML52 Pushbuttons	FO-63504
AML53 Paddle switch covers	FO-63567
AML55 Paddle switch covers	FO-63565
AML54 Rockers	FO-63566
AML56 Rockers	FO-63564